

Pulsafeeder SPO  
27101 Airport Road  
Punta Gorda, FL 33982  
Telephone No. (941) 575-3800



European Union (EU)  
OBL Metering Pumps  
Via Kennedy, 12 - 20090  
Segrate - Milano - Italy

## Product Safety Instructions

**Products:** Pulsatrol MC9000 Series Controllers  
**Model No.** **Controller models:** MC9X, where X can be up to 7 alphanumeric characters overall;



WARNING

Power cord must be disconnected from the power supply before opening the housing of the product.



WARNING

Product must be connected according to all applicable electrical codes.



WARNING

Input power must be 230VAC, single-phase.



WARNING

Trained service personnel are required for making all electrical connections in accordance with local codes. This product contains no operator-serviceable parts.



WARNING

Devices connected to any relay connection must be single phase and is classified to the same voltage as the input voltage to the product. (e. g. 230VAC products support devices 230VAC relay connected exclusively).



WARNING

Power cord must be disconnected from the power supply before opening the housing of the product and make the electrical connections.



NOTE

Make sure replacement fuses to match the classifications listed below. Fuse reference: F1 F2 & type: 5A, IEC 60127-2 250 VAC • timing T Fuse must be certified and same type as original.



NOTE

The product must be connected to a branch of dedicated power (i.e. your own wiring, switch, etc.).



NOTE

In the installation include a switch or circuit breaker, marked as disconnecting the drive device. It must be in proximity near the unit and easily accessible by the user.



NOTE

Panel mounting hardware must support 25 pounds. For locations, see the pattern of mounting holes in the product manual.



NOTE

For additional protection of your instrument, it is recommended to use a surge protector.